



ALL THE RIGHT SPACES

Bret Nusbaum

Owner

Cell: (217) 202-1486

Office: (309) 488-1084

Email: Bnusbaum@mchsi.com

103 N Main St. Farmer City IL

Alltherightspaces.com

CUSTOM CLOSETS

INSTRUCTIONS FOR ASSEMBLY

TOOLS AND MATERIALS NEEDED:

DRILL

T – 25 STAR BIT

WOOD GLUE

STAPLES AND STAPLEGUN TO ATTACH BACK PANEL

DIRECTIONS FOR ASSEMBLY

1. Unbox end unit first. The unit pieces are marked – Top – Bottom
2. Align top grooves and biscuits. Apply glue if desired.
3. Insert biscuits into slides of marked TOP, line up sides, push and screw together.



STEP 2



STEP 3

4. Repeat with **BOTTOM**, making sure to keep finished sides placed correctly.
5. Line up back panel carefully in order to square cabinet unit. Apply the back. We recommend glue and staple gun.



STEP 5

6. Repeat with each unit. Install wall cleat if using. Place units in assigned spots, being sure to level and square up as you go.

7. When all units are properly placed, screw the units together.
If using a wall cleat, you will attach to the wall cleat at this time.



STEP 7

8. Install any additional trim such as crown mold, and finish panels. Please note that finish panels are 5/8" wider to allow for installation with existing baseboard



9. Install self adhesive black pads (included) on the back edge of each shelf or URR placing them toward the outer edges. This aids with a snug fit, and prevents vibration noise.

10. Insert clips flat side up for the URR's. Measure from bottom of unit, (or top of lower component). Component height, plus 1/4".

The back of a URR inserted 'upside down' (as for a sweater pullout or FRO) must be blocked. (See photo) The blocks, screws, and additional keeper clips are included.

To attach blocks – attach to sides of URR 1/2" from back.



Photo of a keeper clip installed on the block portion of a URR.

11. All URR's (any universal rollout receptor) must have keeper clips. A keeper clip is a standard clip inserted upside down with a clear rubber bumper pad installed on the flat side of the clip. This must be installed at the back rail of the top of the URR.
12. Install drawers, roll-outs, etc., into the URR's per the layout.
All components are fully adjustable by the homeowner with no tools required.